



Enclosures -vs.-

“The Kit”

Installation Shoot-out

1. Set factory assembled back section.



2. Set factory assembled front section.



matching overlapping
“tongue & groove” joints.

3. Install internal anchors.



4. Secure wingnut.



5. Close door, place padlock and walk away.



HOTBOX Enclosures
“The Engineered Enclosure”

924 Lane Avenue North
Jacksonville, Florida 32254
Phone 904.786.0204 • Fax 904.783.6965
800.736.0238 • www.hot-box.com

1. Count pieces and read instructions carefully.



2. Assemble pieces "A" to pieces "B".



3. Align each "A" piece with ends of LOA(left over angle).



4. Set piece "D" on pieces "A-B" & fasten externally.



5. Insert screws into outside of "A-B" pieces.



6. Use LOA to pull pieces "B" to LOA, then attaching anchor angle to piece "B".



7. Install roof clips in piece "D", then attach piece "D" to "B". For steps 8 and 9, repeat steps 6 and 7 for the other side.



10. Assemble door hardware when needed.



11. Set "C" pieces in place.



12. Remove wrapper, clean up and GET OUT OF THERE.



Don't let "Kit" enclosures bury you in labor costs! When installed cost is much more than your quoted price, you've bought a "Kit." Get the original. Get a HOT Box® Enclosure!